


F70

Fixing clip

F70 - Fixing clip

- For all F70 runner versions
- Material: plastic and steel
- Integrated tool-free side and depth adjustments
- Recommended pre-drilling \varnothing 2,5 mm
- Fixing to the bottom or to the frontal of the drawer


Dimension of the clip and drilling position




AFGXX3B
Right and left clip with
integrated adjustments

PACKING
 2 BOXES = 100 right pcs. and 100 left pcs.

Fixing to the bottom of the drawer




Fixing to the drawer frontal



It is recommended to pre-drill the bottom or the frontal using the **SGD704UGXA drilling template**, see page 35.

Drawer fixing

Place the drawer on the runners and push forward until completely closed



Drawer removal

Open the drawer completely, press the indicated lever and slide the drawer out of the cabinet

